

DoX-1 Programs

assorted numerically. CC-0 (Bank Select) = MSB, CC-32 (Bank Select) = LSB, PG = Programmchange

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	0	0	Ac Piano	√	121	0	9	Glocken	√
121	1	0	Ac Piano Wide	√	121	1	9	Sistro	
121	2	0	Ac Piano Dark	√	121	0	10	Music Box	√
121	3	0	Grand Piano		121	1	10	Orgel	
121	4	0	Classical Piano		121	0	11	Vibraphone	√
121	5	0	L/R Piano		121	1	11	Vibraphone Wide	√
121	6	0	Piano & Vibes		121	2	11	Vibraphone 2	
121	7	0	Piano & Strings		121	0	12	Marimba	√
121	0	1	Bright Piano	√	121	1	12	Marimba Wide	√
121	1	1	Bright Piano Wide	√	121	2	12	Rimba Key Off	
121	2	1	Piano Pad		121	3	12	Monkey Skuls	
121	3	1	Piano Pad 2		121	4	12	Log Drum	
121	4	1	Piano-String-Pad		121	5	12	Mallet Clock	
121	0	2	El.Grand Piano	√	121	6	12	Balaphon	
121	1	2	El.Grand Wide	√	121	0	13	Xylophone	√
121	2	2	M1 Piano		121	0	14	Tubular Bell	√
121	3	2	90's Piano		121	1	14	Church Bell	√
121	4	2	2000's Piano		121	2	14	Carillon	√
121	5	2	Chorus Piano		121	3	14	Church Bell 2	√
121	6	2	Piano Layers		121	0	15	Dulcimer	√
121	0	3	Honky-Tonk	√	121	1	15	Santur	√
121	1	3	Honky-Wide	√	121	0	16	Drawbar Organ	√
121	0	4	E.Piano 1	√	121	1	16	Det. Drawbar Organ	√
121	1	4	Detuned EP 1	√	121	2	16	Italian 60's Organ	√
121	2	4	EP1 Veloc.-Switch	√	121	3	16	Drawbar Organ 2	√
121	3	4	60's El-Piano	√	121	4	16	Dark Jazz Organ	
121	4	4	Vintage EP		121	5	16	Iper DarkOrgan	
121	5	4	Pro Dyno EP		121	6	16	Full Drawbar Organ	
121	6	4	Pro Stage EP		121	7	16	DWGS Organ	
121	7	4	Studio El.-Piano		121	8	16	Jazz Organ	
121	8	4	R&B El.-Piano		121	9	16	Gospel Organ	
121	9	4	Thin El.-Piano		121	10	16	Good Old B	
121	10	4	DynoTine EP		121	11	16	VOX Legend	
121	11	4	Club El.-Piano		121	12	16	Arabian Organ	
121	0	5	E.Piano 2	√	121	0	17	Perc. Organ	√
121	1	5	Detuned EP 2	√	121	1	17	Det.Perc Organ	√
121	2	5	EP2 Veloc.sw	√	121	2	17	Perc.Organ 2	√
121	3	5	EP Legend	√	121	3	17	Old Wheels	
121	4	5	EP Phase	√	121	4	17	Percussive BX3	
121	5	5	Syn Piano XE		121	5	17	M1 Organ	
121	6	5	Stereo Dig EP		121	6	17	Tekno Org. Bass	
121	7	5	Classic Digi EP		121	7	17	BX3 Short Decay	
121	8	5	Hybrid EP		121	8	17	Rotary Organ	
121	9	5	Class.Tines		121	0	18	Rock Organ	√
121	10	5	PhantomTine		121	1	18	BX3 Velo Sw	
121	11	5	DW8000 EP		121	2	18	Killer B	
121	12	5	Sweeping EP		121	3	18	Dirty B	
121	3	5	WhitePad EP		121	4	18	Classic Click Organ	
121	0	6	Harpsichord	√	121	5	18	Dist.Organ	
121	1	6	Harpsi Oct.	√	121	6	18	Super BX Perc	
121	2	6	Harpsi Wide	√	121	7	18	Dirty Jazz Organ	
121	3	6	Harpsi K.Off	√	121	8	18	Perc Short Decay	
121	4	6	Harpsi Korg		121	9	18	Perc.Wheels	
121	0	7	Clavinet	√	121	10	18	Jimmy Organ	
121	1	7	Pulse Clavinet	√	121	0	19	ChurchOrg.1	√
121	2	7	Clav Wah		121	1	19	Church Orch.-Mix	√
121	3	7	Clav Snap		121	2	19	Det. Church Organ	√
121	4	7	Sticky Clavi		121	3	19	PipeMixture	
121	0	8	Celesta	√	121	4	19	ChurchPipes	

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	5	19	Full Pipes		121	11	27	Country Nu	
121	6	19	Pipe Tutti		121	12	27	Funky Wha Sw	
121	7	19	Positive Organ		121	0	28	Muted Gtr	√
121	0	20	Reed Organ	√	121	1	28	Funky Cut Gtr	√
121	1	20	Puff Organ	√	121	2	28	MuteVelo Gtr	√
121	2	20	Small Pipe Organ		121	3	28	Jazz Man Gtr	√
121	3	20	Flauto Pipes		121	4	28	R&R Gtr	
121	0	21	Accordion	√	121	5	28	Stra.Chime Gtr	
121	1	21	Accordion 2	√	121	6	28	Clean Mute Gtr	
121	2	21	Akordeon		121	7	28	Rhythm Elec. Gtr	
121	3	21	Musette 1		121	8	28	Clean Funk Gtr	
121	4	21	Musette 2		121	9	28	Disto Mute Gtr	
121	5	21	Musette Clar		121	0	29	Overdrive Gtr	√
121	6	21	Fisa 16+8		121	1	29	Guitar Pinch	√
121	7	21	Fisa 16+4		121	0	30	Distortion Gtr	√
121	8	21	Fisa Master		121	1	30	Feedback Gtr	√
121	9	21	Cassotto		121	2	30	Dist Rhythm Gtr	√
121	10	21	Arab.Accordion		121	3	30	JoystGtr Y- Gtr	
121	0	22	Harmonica	√	121	4	30	PowerChords Gtr	
121	1	22	Sweet Harmonica		121	5	30	Mute Monster Gtr	
121	2	22	Harmonica 2		121	6	30	Wet Dist Gtr	
121	0	23	TangoAccord	√	121	7	30	Solo Dist Gtr	
121	1	23	Fisa Tango		121	8	30	Stereo Dist Gtr	
121	0	24	Nylon Gtr	√	121	0	31	Gtr Harmonic	√
121	1	24	Ukulele	√	121	1	31	Gtr Feedback	√
121	2	24	Nylon Key Off	√	121	2	31	EG Harmonics	
121	3	24	Nylon Gtr 2	√	121	0	32	Acous. Bass	√
121	4	24	Nylon Bossa		121	1	32	AcBass Buzz	
121	5	24	AcGtrKeyOff		121	2	32	Bass & Ride	
121	6	24	Spanish Gtr		121	0	33	Finger Bass	√
121	7	24	Gtr Strings		121	1	33	Finger Slap	√
121	0	24	Steel Gtr	√	121	2	33	Fingered El.-Bass	
121	1	25	12-String Gtr	√	121	3	33	Fingered El.-Bass 2	
121	2	25	Mandolin	√	121	4	33	Fing.El. Bass3	
121	3	25	Steel&Body	√	121	5	33	Stick Bass	
121	4	25	Steel Gtr		121	0	34	Picked Bass	√
121	5	25	Stereo 12-Strings		121	1	34	Pick Electric Bass	
121	6	25	Hackbrett		121	2	34	Pick El. Bass 2	
121	7	25	FingerK.Off		121	3	34	Stein Bass	
121	8	25	Finger Tips		121	4	34	Gtr. Bass	
121	9	25	St.Folk Gtr		121	5	34	Bass Mute	
121	10	25	Mandol.K Off		121	0	35	Fretless Bass	√
121	11	25	MandoTrem		121	1	35	Fretless Bass 2	
121	12	25	Reso.-Gtr		121	2	35	Fretless Sw	
121	0	26	Jazz Gtr	√	121	3	35	Sweet Fretless	
121	1	26	Pedal Steel Gtr	√	121	4	35	DarkR&B Bass	
121	2	26	Club J.Gtr1		121	0	36	Slap Bass 1	√
121	3	26	Club J.Gtr2		121	1	36	Super Switch Bass	
121	4	26	Pedal Steel 2		121	2	36	Super Switch Bass 2	
121	0	27	Clean Gtr	√	121	0	37	Slap Bass 2	√
121	1	27	Det. Clean Gtr	√	121	1	37	Thumb Bass	
121	2	27	Mid Tone Gtr	√	121	2	37	Dyna Bass	
121	3	27	Chorus Gtr		121	0	38	Synth Bass 1	√
121	4	27	Vintage Strat		121	1	38	Syn Bass War	√
121	5	27	Process El Gtr		121	2	38	Syn Bass Reso	√
121	6	27	Single Coil		121	3	38	Clav Bass Bass	√
121	7	27	New Strat		121	4	38	Hammer Bass	√
121	8	27	Guitarish		121	5	38	30303 Bass	
121	9	27	L&R El. Gtr		121	6	38	30303 Square	
121	10	27	L&R El. Gtr 2		121	7	38	Bass Square	

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	8	38	SynBass Resonance		121	5	52	Take Voices 2	
121	9	38	Digi Bass 1		121	6	52	Oooh Choir	
121	10	38	Digi Bass 2		121	7	52	Aaah Choir	
121	11	38	Digi Bass 3		121	8	52	Mmmh Choir	
121	12	38	Blind As A Bat		121	9	52	Oh-Ah Voices	
121	13	38	Jungle Bass		121	10	52	Slow Choir	
121	14	38	Auto Pilot Syn Bass		121	11	52	Grand Choir	
121	15	38	Hybrid Bass		121	12	52	Choir Light	
121	16	38	Dr. Octave		121	13	52	String Choir	
121	0	39	Synth Bass 2	√	121	0	53	Voice Oohs	√
121	1	39	Attack Bass	√	121	1	53	Humming	√
121	2	39	Rubber Bass	√	121	2	53	Doolally	
121	3	39	Attack Pulse	√	121	3	53	Airways	
121	4	39	Euro Bass		121	0	54	Synth Voice	√
121	5	39	Jungle Rez		121	1	54	AnalogVoice	√
121	6	39	Nasty Bass		121	2	54	Vocalesque	
121	7	39	Phat Bass		121	3	54	Vocalscape	
121	8	39	Poinker Bass		121	4	54	ClassicVox	
121	0	40	Violin	√	121	5	54	Dream Voice	
121	1	40	SlowAttViolin	√	121	0	55	Orchestra Hit	√
121	2	40	Solo Violin		121	1	55	Brass Hit Plus	√
121	3	40	Slow Violin	√	121	2	55	6 th Hit	√
121	0	41	Viola	√	121	3	55	Euro Hit	√
121	0	42	Cello	√	121	4	55	Brass Impact	
121	0	43	Contrabass	√	121	5	55	Hit In India	
121	0	44	Tremolo Strings	√	121	6	55	Wild Arp	
121	0	45	Pizzicato Stereo	√	121	7	55	Flip Blip	
121	1	45	Pizz-Ensemble		121	0	56	Trumpet	√
121	2	45	Pizz-Section		121	1	56	Dark Trumpet	√
121	3	45	Dbl Strings		121	2	56	Trumpet 2	
121	0	46	OrchestraHarp	√	121	3	56	Mono Trumpet	
121	1	46	Yang Chin	√	121	4	56	Trumpet Expression	
121	0	47	Timpani	√	121	5	56	Trumpet Pitch	
121	0	48	StringsEnsemble 1	√	121	6	56	Dual Trumpet	
121	1	48	String&Brass	√	121	7	56	Flugelhorn	
121	2	48	60s Strings	√	121	8	56	Warm Flugel	
121	3	48	Stereo Strings		121	9	56	BeBop Cornet	
121	4	48	Legato Strings		121	0	57	Trombone	√
121	5	48	i3 Strings		121	1	57	Trombone 2	√
121	6	48	N Strings		121	2	57	Bright Trombone	√
121	7	48	Arco Strings		121	3	57	Hard Trombone	
121	8	48	Octave Strings		121	4	57	Soft Trombone	
121	9	48	String Quart		121	5	57	Pitch Trombone	
121	10	48	Symph. Bows		121	0	58	Tuba	√
121	11	48	Ensemble & Solo		121	1	58	Oberkr. Tuba	
121	12	48	Camera Strings		121	2	58	Tuba Gold	
121	13	48	Arab. Strings		121	3	58	Dynabone	
121	0	49	Strings Ens2	√	121	0	59	Muted Tp	√
121	1	49	Sweeper Strings		121	1	59	Muted Tp 2	√
121	0	50	Syn Strings1	√	121	2	59	Wha Trumpet	
121	1	50	Syn Strings3	√	121	3	59	Mute Ensemble	
121	2	50	Analog Strings		121	4	59	Mute Ensemble 2	
121	3	50	Analog Velve		121	0	60	French Horn	√
121	4	50	Odyssey		121	1	60	French Horn 2	√
121	0	51	Syn Strings2	√	121	2	60	French Section	
121	0	52	Choir Aahs	√	121	3	60	Classic Horn	
121	1	52	Choir Aahs2	√	121	4	60	Horns & Ensemble	
121	2	52	Oooh Voices		121	0	61	Brass Sect.1	√
121	3	52	Oh Slow Voice		121	1	61	Brass Sect.2	√
121	4	52	Take Voices		121	2	61	Tight Brass	

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	3	61	Glen & Friend		121	4	71	Sect Winds2	
121	4	61	BigBand Brass		121	5	71	Clarinet Ensemble	
121	5	61	Sax & Brass		121	6	71	Woodwinds	
121	6	61	Glenn & Boys		121	7	71	Folk Clarinet	
121	7	61	Trp & Brass		121	0	72	Piccolo	√
121	8	61	Attack Brass		121	1	72	Small Orchestra	
121	9	61	Trumpet Ensemble		121	2	72	Nay	
121	10	61	Trombone Ensemble		121	0	73	Flute	√
121	11	61	Trombones		121	1	73	Jazz Flute	
121	12	61	Tight Brass 2		121	2	73	Flute Switch	
121	13	61	Fat Brass		121	3	73	Flute Dyn 5 th	
121	14	61	Dyna Brass		121	4	73	Flute Frull	
121	15	61	Brass Expr.		121	5	73	Orch. Flute	
121	16	61	Brass Band		121	6	73	Flute Muted	
121	17	61	Film Brass		121	7	73	Wooden Flute	
121	18	61	Brass Slow		121	9	73	Bambu Flute	
121	19	61	Fanfare		121	0	74	Flute 2	
121	20	61	Movie Brass		121	1	74	Recorder	√
121	21	61	Power Brass		121	0	75	Recorder 2	
121	22	61	Dyna Brass 2		121	1	75	Pan Flute	√
121	23	61	Sfz Brass		121	0	76	Kawala	
121	24	61	Dbl Brass		121	0	77	Blown Bottle	√
121	25	61	Brass Hit		121	1	77	Shakuhachi	√
121	26	61	Brass Fall		121	2	77	Old Shaku	
121	0	62	Syn Brass 1	√	121	0	78	Shaku 2	
121	1	62	Syn Brass 3	√	121	1	78	Whistle	4
121	2	62	Analog Brass 1	√	121	0	79	Whistle 2	
121	3	62	Jump Brass	√	121	0	80	Ocarina	√
121	4	62	Electrik Brass		121	1	80	Lead Square	√
121	5	62	Syn Brass 5		121	2	80	Lead Square 2	√
121	0	63	Syn Brass 2	√	121	3	80	Lead Sine	√
121	1	63	Syn Brass 4	√	121	4	80	Old Portam	
121	2	63	Analog Brass 2	√	121	5	80	Dance Lead	
121	3	63	Brass Pad	√	121	6	80	Wave Lead	
121	4	63	Big Panner 1	√	121	7	80	Sine Wave	
121	0	64	Soprano Sax	√	121	8	80	Analog Lead	
121	1	64	Sweet Soprano		121	9	80	Old & Analog	
121	0	65	Alto Sax	√	121	10	80	Gliding Seq.	
121	1	65	Alto Breath		121	11	80	Sine Switch	
121	2	65	Sax Ensemble		121	0	81	Square Rez	
121	3	65	Breathy Alto		121	1	81	Lead Saw	√
121	4	65	Alt SaxGrowl		121	2	81	Lead Saw 2	√
121	0	66	Tenor Sax	√	121	3	81	Lead SawPuls	√
121	1	66	Tenor Noise		121	4	81	Lead DblSaw	√
121	2	66	Soft Tenor		121	5	81	Seq. Analog	√
121	3	66	Tenor Breath		121	6	81	Power Saw	
121	4	66	Tenor Growl		121	7	81	Octo Lead	
121	5	66	Folk Sax		121	8	81	Seq Lead	
121	0	67	Baritone Sax	√	121	9	81	Phat Saw Lead	
121	1	67	Barit Growl		121	10	81	Glide Lead	
121	2	67	Breathy Bari		121	11	81	Fire Wave	
121	0	68	Oboe	√	121	12	81	Rezbo	
121	1	68	Double Reed		121	0	82	Syn Pianoid	
121	0	69	English Horn	√	121	0	83	Calliope	√
121	1	69	English Horn 2		121	0	84	Chiffer	√
121	0	70	Bassoon	√	121	0	84	Charang	√
121	0	71	Clarinet	√	121	1	84	Wire Lead	√
121	1	71	Jazz Clarinet		121	2	84	Synchro City	
121	2	71	Clarinet G		121	3	84	Sync Kron	
121	3	71	Sect Winds		121	4	84	Metallic Rez	

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	5	84	Brian Sync		121	3	95	Dark Element	
121	6	84	Arp Twins		121	4	95	Mellow Pad	
121	0	85	Voice Lead	√	121	5	95	Cinema Pad	
121	1	85	Ether Voices		121	0	96	Ice Rain	√
121	2	85	Cyber Choir		121	1	96	Motion Ocean	
121	0	86	Fifths Lead	√	121	2	96	Caribbean	
121	1	86	Crimson5 ^{ths}		121	0	97	Soundtrack	√
121	0	87	Bass & Lead	√	121	1	97	Air Clouds	
121	1	87	Soft Wrl	√	121	2	97	Reso Down	
121	2	87	ElectroLead		121	3	97	Tinklin Pad	
121	3	87	Rich Lead		121	4	97	Pods In Pad	
121	4	87	Thin Ana Lead		121	5	97	Noble Pad	
121	5	87	Espress Lead		121	6	97	Rave	
121	6	87	HipHop Lead		121	7	97	Elastic Pad	
121	7	87	Square Bass		121	0	98	Crystal	√
121	8	87	Big & Raw		121	1	98	SynthMallet	√
121	9	87	Cat Lead		121	2	98	Vs Bell Boy	
121	0	88	New Age Pad	√	121	3	98	KrystalBell	
121	1	88	Virtual Travel		121	4	98	Digi Bell	
121	2	88	Arp Angeles		121	5	98	Moving Bell	
121	0	89	Warm Pad	√	121	6	98	Bell Pad	
121	1	89	Sine Pad	√	121	7	98	Bell Choir	
121	2	89	Master Pad		121	0	99	Atmosphere	√
121	3	89	Power Synth		121	0	100	Brightness	√
121	4	89	The Pad		121	1	100	Lonely Spin	
121	5	89	Money Pad		121	2	100	Syn Ghostly	
121	6	89	Dark Pad		121	0	101	Goblins	√
121	7	89	Freedom Pad		121	1	101	MotionRaver	
121	8	89	Analog Pad		121	2	101	Digi IcePad	
121	9	89	Analog Pad2		121	0	102	Echo Drops	√
121	0	90	Polysynth	√	121	1	102	Echo Bell	√
121	1	90	Reso Sweep		121	2	102	Echo Pan	√
121	2	90	Sky Watcher		121	3	102	Band Passed	
121	3	90	Syn Sweeper		121	4	102	Pan Reso	
121	4	90	Super Sweep		121	5	102	Moon Cycles	
121	5	90	Wave Sweep		121	0	103	Star Theme	√
121	6	90	Cross Sweep		121	0	104	Sitar	√
121	7	90	Dig Poly Six		121	1	104	Sitar 2	√
121	8	90	Noisy Stabb		121	2	104	Sitar Tambou	
121	9	90	Mega Synth		121	3	104	Indian Stars	
121	10	90	TecnoPhonic		121	4	104	Indian Frets	
121	11	90	Farluce		121	5	104	Bouzouki	
121	0	91	Choir Pad	√	121	6	104	Tambra	
121	1	91	Itopia Pad	√	121	0	105	Banjo	√
121	2	91	Fresh Air		121	1	105	Banjo Key Off	
121	3	91	Heaven		121	2	105	Oud	
121	4	91	Pop Syn Pad		121	3	105	Jaw Harp	
121	5	91	Future Pad		121	0	106	Shamisen	√
121	6	91	Tsunami Wave		121	0	107	Koto	√
121	7	91	Fresh Breath		121	1	107	Taisho Koto	√
121	8	91	Ravelian Pad		121	2	107	Kanun	
121	9	91	Full Vox Pad		121	3	107	Kanun Tremolo	
121	10	91	Dance ReMix		121	4	107	Kanun Mix	
121	0	92	Bowed Glass	√	121	0	108	Kalimba	√
121	0	93	MetallicPad	√	121	1	108	Velo Kalimba	
121	1	93	Cosmic		121	0	109	Bag Pipe	√
121	0	94	Halo Pad	√	121	1	109	War Pipes	
121	0	95	Sweep Pad	√	121	0	110	Fiddle	√
121	1	95	Astral Dream		121	0	111	Shanai	√
121	2	95	Meditate		121	1	111	Zurna	

CC-0	CC-32	PG	Programm - Name	GM-2	CC-0	CC-32	PG	Programm - Name	GM-2
121	2	111	Hichiriki		121	0	127	Gun Shot	√
121	0	112	Tinkle Bell	√	121	1	127	Machine Gun	√
121	1	112	Gamelan		121	2	127	Lasergun	√
121	2	112	Bali Gamelan		121	3	127	Explosion SFX	√
121	3	112	Garbage Mall		DoX-1 Drum-Kits				
121	0	113	Agogo	√					
121	0	114	Steel Drums	√					
121	1	114	Warm Steel		PG	Kit - Name	Note		GM-2
121	0	115	Woodblock	√	0	Std. Kit 1			√
121	1	115	Castanets	√	1	Std. Kit 2			
121	0	116	Taiko Drum	√	2	Std. Kit 3			
121	1	116	Concert BD	√	3	Acoustic Kit			
121	0	117	Melodic Toms	√	4	Std. Kit 4			
121	1	117	Melodic Toms 2	√	5	(<i>remap to 0 or 1</i>)			
121	2	117	Reverse Toms		8	Room Kit 1			√
121	0	118	Synth Drum	√	9	HipHop Kit 1			
121	1	118	Rhythm Box Toms	√	10	Jungle Kit			
121	2	118	Electronic Drum	√	11	Techno Kit 1			
121	3	118	Reverse Snare		12	Room Kit 2			
121	0	119	Reverse Cymbal		13	HipHop Kit 2			
121	1	119	Dragon Gong		14	Techno Kit 2			
121	0	120	Gt. Fret Noise	√	15	Techno Kit 3			
121	1	120	Gtr. Cut Noise	√	16	Power Kit 1			√
121	2	120	Ac. Bass Strng	√	17	Power Kit 2			
121	3	120	Vox Wah Chick		18-23	(<i>remap to 16 or 17</i>)			
121	0	121	Breath Noise	√	24	Electro Kit			√
121	1	121	Flute Click	√	25	Analog Kit			√
121	0	122	Seashore	√	26	House Kit1			
121	1	122	Rain	√	27	House Kit2			
121	2	122	Thunder	√	28	House Kit3			
121	3	122	Wind	√	29	House Kit4			
121	4	122	Stream	√	30-31	(<i>remap to 24 or 25</i>)			
121	5	122	Bubble	√	32	Jazz Kit			√
121	0	123	Bird Tweet	√	33-39	(<i>remap to 32 or 33</i>)			
121	1	123	Dog	√	40	Brush Kit1			√
121	2	123	HorseGallop	√	41	Brush V.S.2			
121	3	123	Bird Tweet 2	√	42- 47	(<i>remap to 40 or 41</i>)			
121	0	124	Telephone 1	√	48	OrchestraKit			√
121	1	124	Telephone 2	√	49	(<i>remap to 48 bzw. 49</i>)			
121	2	124	Door Creak	√	50	BDrum&SDrum			
121	3	124	Door	√	51	(<i>remap to 116 or 117</i>)			
121	4	124	Scratch	√	52-55	(<i>remap to 48 or 49</i>)			
121	5	124	Wind Chime	√	56	FX Kit			√
121	0	125	Helicopter	√	57-63	(<i>remap to 56 or 57</i>)			
121	1	125	Car Engine	√	64	Percus.Kit1			
121	2	125	Car Stop	√	65	Latin P.Kit			
121	3	125	Car Pass	√	66	TRI-Per.Kit			
121	4	125	Car Crash	√	67	i30 Perc.Kit			
121	5	125	Siren	√	68-71	(<i>remap to 64 or 65</i>)			
121	6	125	Train	√	72-115	(<i>remap to 0 or 1</i>)			
121	7	125	Jetplane	√	116	Arabian Kit 1			
121	8	125	Starship	√	117	Arabian Kit 2			
121	9	125	Burst Noise	√	118-127	(<i>remap to 0 or 1</i>)			
121	0	126	Applause	√	Note: On midi-channel 10 (drums) Controller 0 and 32 are not needed. Listings of all the samples and detailed descriptions for all Drumkits you can find on the reconciled CD-ROM				
121	1	126	Laughing	√					
121	2	126	Screaming	√					
121	3	126	Punch	√					
121	4	126	Heart Beat	√					
121	5	126	Footsteps	√					
121	6	126	Stadium						